

Showerhead Care



Clean Fast and Protect

2-stage procedure for descaling and disinfecting showerheads

Descaling



Make up a solution of **CLEAN FAST** at a dilution rate of 1:4 with warm water.

Dismantle the showerhead and hose and soak in the solution of **CLEAN FAST** for 30 minutes.

Agitation with a nylon scrubbing brush may be necessary to remove heavy soil and limescale.

Discard used solution safely and flush the showerhead and hose with clean water.

Disinfecting



To kill a range of bacteria including **Legionella pneumophila***:

Make up a solution of **PROTECT** at a dilution rate of 1:100 with warm water.

Add showerhead and hose to the solution and soak for a minimum of 5 minutes.

Discard used solution safely and flush the showerhead and hose with clean water.

Re-assemble showerhead and hose ready for use.

This procedure should be carried out every 3 months.

* PROTECT is suitable for disinfecting showerheads only and should not be used in water systems for the control of Legionella.



Evans Vanodine
GLOBAL HYGIENE SOLUTIONS



www.evansvanodine.co.uk