



# e:dose

## Ice Cream Equipment 3 Step Cleaning System

### SCOOP



#### STEP 1 -

For initial clean, make up a solution of:  
1 part EC4 SANITISER to 60 parts water in a container.  
Dip and shake scoop to remove majority of ice cream.

#### STEP 2 -

Make up a solution of  
1 part EC4 SANITISER to 60 parts water in a container.  
Dip and shake scoop to sanitise.


#### STEP 3 -

Rinse with clean water prior to use.


*Change solution regularly*



#### STEP 1 -

2 x  per 1.25lt water

#### STEP 2 -

2 x  per 1.25lt water

### MACHINE



#### STEP 1 -

For initial clean, make up a solution of:  
1 part EC4 SANITISER to 60 parts warm water.  
Operate machine to draw solution all the way through  
the dispensing system.

#### STEP 2 -

Make up a solution of  
1 part EC4 SANITISER to 100 parts warm water. Operate machine  
to draw solution into the dispensing system and leave overnight.

#### STEP 3 -

Pump clean water through the dispensing system prior to use.



#### STEP 1 -

4 x  in 2.5lt water

#### STEP 2 -

5 x  in 5lt water