



ICE MACHINE CLEANING



EC4 Sanitiser Super concentrate sanitiser

Unperfumed multi purpose cleaner and disinfectant.
Passes EN 1276 under dirty conditions at 1:60 with
a 30 second contact time.



Consult manufacturers' guidelines before cleaning and disinfecting your machine. If your machine has an automatic wash programme follow the method below for removable parts only.

Concentration	Equipment
Make up a solution of EC4 at a dilution rate of 1:60 in a spray bottle (10ml per 600ml water)	Bucket, disposable cloth, soft nylon brush and warm water

MANUAL CLEANING AND DISINFECTION METHOD

1. Unplug machine, turn off water supply (if applicable) and leave to defrost.
2. Empty machine of all ice and water using a plastic scoop. Never use a glass, there may be a risk of glass fragments being left in the machine.
3. Remove any components, which can be cleaned separately, as per the machine's instructions.
4. Prepare a solution of EC4 in a spray bottle.
5. Spray EC4 inside and outside of the machine and clean with a disposable cloth and a soft nylon brush, if required, ensuring that any dirt or slime is removed.
6. To disinfect, spray EC4 inside and outside of the machine and leave for 30 seconds.
7. Rinse using clean water in a bucket and wipe with a clean cloth.
8. Leave to air dry.
9. The components can be cleaned and disinfected using the same procedure above.
10. Replace the removable components.
11. Restart the machine.
12. Discard the first batch of ice.



INSPECT MACHINE REGULARLY

For build-up of dirt, rust, limescale and mould

MAINTENANCE PROGRAMME

Include cleaning and disinfection of the ice machine in your equipment cleaning programme